

INSTRUCTIONS: HOW TO REPLACE A LAPSTRAP/HARNESS FOR THE INFANT HIGHCHAIR

- 1) Turn chair upside down and place on a flat, firm surface.
-



- 2) Identify the 2 screws holding the strap in place.
-


- 3) Remove the 2 screws holding the damaged strap and discard.
-



- 4) Lay the new strap against the back of the high chair with the buckle facing you.
-



- 5) Put the new screw into washer (supplied) and then into the hole in one end of the new strap.
-



- 6) Locate the screw hole in the wooden base and screw in the end of the new strap.
-



- 7) Repeat the above (6) on the other end of the new strap until tight.
-



- 8) Return the chair to upright position, test buckle by opening and closing. If all OK return chair to use.
-