



## **MAGRINI NAPPY CHANGING UNIT** **Models MT80 - Countertop**

### **Cleaning Instructions**

To ensure that the changing table retains its original colour and good looks a regular cleaning routine is essential.

The nappy changing unit may be washed and wiped with a damp soft cloth or sponge. Use of mild detergent and warm water will remove the majority of dust and stains. For more obstinate stains a domestic cream cleaner can be used. Do not use any abrasive cloths, caustic or solvent cleaners as this may damage the unit.

In order to disinfect the unit, sodium hypochlorite can be used at low concentrations (10,000 ppm = 1%). It should not be left in permanent contact with the polymer and should be fully rinsed off with fresh water following cleaning.

### **Maintenance instructions**

Check that the unit is securely fixed to the counter.

Ensure warning label is in place on the back of the unit and general cleanliness is within given guidelines.

Always use genuine Magrini replacement parts.

### **Product Warranty**

Magrini warrants its Baby Changing Units to be free from defects in materials and workmanship, under normal use and service, for a period of one year from the date of purchase, when installed and maintained in accordance with Magrini's written instructions.

Without limiting the generality of the foregoing, this warranty does not cover:-  
disposable bed liners, product misuse, theft or vandalism, tampering or misapplication, loads in excess of stated maxima or improper installation.

Magrini's liability will be limited, at Magrini's option, to repair or replacement with respect to any claim made within the applicable warranty period referred to above.

MT80004

03/17

#### **Magrini Ltd**

Unit 5 Maybrook Industrial Estate, Brownhills, Walsall, West Midlands WS8 7DG

Tel: 01543 375311 Email: [sales@magrini.co.uk](mailto:sales@magrini.co.uk) [www.magrini.co.uk](http://www.magrini.co.uk)