



Replacing the gas strut on Magrini MC75 Stainless Steel Baby Changing Unit

- Remove cover by loosening the 4 retaining screws
- Lay the unit on its front
- Gently knock the retaining pin through halfway so as to release the fitting at the top of the gas strut; discard the used washer
- Unscrew the strut, screw the fitting onto the new strut
- Fit the new gas strut assembly into the base fitting and tighten
- Fit the pin back through the top fitting, push a star washer over the pin
- Tap the pin through so it is secure both sides
- Replace the cover and screws

Magrini Ltd Unit 5 Maybrook Industrial Estate, Brownhills, Walsall, West Midlands WS8 7DG

Telephone: 01543 375311

www.magrini.co.uk